



## Cindy's Jumpers Hot Dog Steamer Rental Operating Instructions

### **INSTALLATION**

1. Place the unit in a prominent location on a level counter, where the hot dogs machine will attract attention.
2. Precaution should be taken so customers do not come in contact with the hot unit.
3. Plug the power cord into a suitable (20 amp) 120 volt outlet that can provide the required wattage. Having other appliances on a circuit, may prevent your unit from receiving the necessary voltage.

### **GENERAL OPERATING PROCEDURES**

1. Add water to the bottom of the hot dog steamer machine, do not overfill.
2. Place the hot dog franks on the smaller compartment and the buns on the larger compartment inside the machine.
3. Turn the machine to the ON position. Turn the heating element to the high setting for about 20-30 minutes. Then turn down to number, 3 or 4, a middle heat setting.

#### **NOTE:**

Failure to turn down the heating temperature will cause the franks to over cook and the buns to become soggy with too much steam.

### **COOKING**

Cooking time will vary depending on the starting temperature and the qualities of the product.

### **CLEANING**

No Cleaning is required just empty out all the leftover hot dogs, buns and water.